




















































SHARP社製 壁掛け金具対応表

掲載がないテレビ型番については、対応確認をいたしますのでお問い合わせください

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA034	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	40~85型	~50型	32~75型	32~75型	32~65型	50~85型	32~65型	42~100型	37~70型	~100型	32~65型	43型まで	15~43型
																		
85	4T-C85HV1	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
	8T-C85DX1	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
80	8T-C80AX1	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
	LC-80GL7	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-80XL10	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-80XL9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-80XU30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	PN-H801	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
77	4T-C77EQ1	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
	4T-C77GQ1	x	x	x	x	○	x	x	x	○	x	○	x	○	x	x	x	x
75	4T-C75EP1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	4T-C75EL1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	4T-C75FN1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	4T-C75GL1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	4T-C75GN1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	4T-C75GP1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	4T-C75HP1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
	8T-C75DX1	x	x	x	x	○	x	○	○	x	○	x	○	x	○	x	x	x
PN-HW751	x	x	x	x	○	x	○※2	x	x	○	x	○	x	○	x	x	x	x
70	4T-C70AU1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C70BN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C70CN1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	4T-C70DN1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	4T-C70EN1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	4T-C70EP1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	8T-C70AX1	x	x	x	○	○	x	○	x	○	x	○	○	○	○	x	x	x
	8T-C70BW1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	8T-C70CX1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	8T-C70DW1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	LC-70UD20	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-70US4	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	LC-70X5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-70X500	x	x	x	○	○	x	○	x	x	○	x	○	○	○	x	x	x
	LC-70XG35	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-70XL10	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	PN-E702	x	x	x	x	○	x	○	x	x	○	x	○	○	○	x	x	x
	PN-E703	x	x	x	x	○	x	○	x	x	○	x	○	○	○	x	x	x
	PN-L703B	x	x	x	x	x	x	○	x	x	x	x	x	x	x	x	x	x
	PN-R701	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
PN-R703	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x	
PN-R706	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x	

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA034	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	40~85型	~50型	32~75型	32~75型	32~65型	50~85型	32~65型	42~100型	37~70型	~100型	32~65型	43型まで	15~43型
																		
43	2T-C43GE2	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	×
	2T-C43GF2	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	×
	4T-C43AM1	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	×
	4T-C43CL1	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	○
	4T-C43CN1	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	○
	4T-C43DL1	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	○
	4T-C43DN2	○	○	○	○	○	○	×	○	○	×	×	○	×	○	○	×	○
	4T-C43EL1	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	4T-C43FN2	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	4T-C43GL1	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	4T-C43GP2	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	4T-C43HP2	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	PN-HS431	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	PN-HW431	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	○	○
PN-W435A	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	○	○	
PN-Y436	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	○	×	
42	2T-C42BE1	×	○※1	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	4T-C42DJ1	○	○	○	×	×	○	×	○	×	×	×	×	×	×	○	×	×
	4T-C42EJ1	○	○	○	×	×	○	×	○	×	×	×	×	×	×	○	×	×
	4T-C42EQ2	○	○	○	○	○	×	×	○	○	×	×	○	×	○	○	×	×
	4T-C42FL1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	4T-C42GQ2	○	○	○	×	○	○	○	○	○	×	○	○	○	○	○	×	×
	4T-C42HQ2	○	○	○	×	○	○	○	○	○	×	○	○	○	○	○	×	×
	LC-42DS5	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	×	×
	LC-42DS6	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	×	×
	LC-42EX5	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	×	×
	LC-42GX5	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	PN-R426	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	×	×
PN-Y425	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	×	×	
40	2T-B40AB1	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	2T-C40AE1	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	2T-C40BE1	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	4T-C40AJ1	○	○	○	○	○	○	×	○	○	×	×	×	×	×	○	×	○
	4T-C40BH1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	○
	4T-C40BJ1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	○	○
	4T-C40CL1	○	○	×	×	×	○	×	×	×	×	×	×	×	×	×	×	○
	LB-T401	○	○	×	×	×	○	×	×	×	×	×	×	×	×	○	○	○
	LC-40AE6	○	○	○	○	○	○	○	○	○	×	○	×	○	○	○	×	×
	LC-40AE7	○	○	○	○	○	○	×	○	○	×	×	×	×	○	○	×	×
	LC-40AJ1	○	○	○	○	○	○	○	○	○	×	×	×	×	○	○	×	○
	LC-40BH11	×	○※1	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-40BH30	×	○※1	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-40DR9	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-40DS6	○	○	○	○	○	○	○	○	○	×	○	×	○	○	○	×	×
	LC-40DX2	○	×	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-40E40	○	×	○	×	×	×	×	×	×	×	×	×	×	×	○	×	×
	LC-40E9	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
LC-40G7	○	×	○	×	○	×	×	○	○	×	×	×	×	○	○	×	×	
LC-40G9	○	×	○	×	○	×	×	○	○	×	×	×	×	○	○	×	×	

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA034	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	40~85型	~50型	32~75型	32~75型	32~65型	50~85型	32~65型	42~100型	37~70型	~100型	32~65型	43型まで	15~43型
																		
40	LC-40H11	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40H20	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40H30	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40H40	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40H9	○	x	x	x	○	x	x	○	○	x	x	x	x	x	○	x	x
	LC-40HW10	○	x	x	○	○	x	x	○	○	x	x	x	x	x	○	x	x
	LC-40HW20	○	○	x	○	○	○	x	○	○	x	x	x	x	x	○	x	○
	LC-40HW35	○	○	x	○	○	○	x	○	○	x	x	x	x	x	○	x	○
	LC-40J10	○	x	x	x	○	x	x	○	○	x	x	x	x	○	○	x	x
	LC-40LV3	○	x	x	x	x	x	x	x	x	x	x	x	x	x	○	x	x
	LC-40LX3	○	x	x	x	x	x	x	x	x	x	x	x	x	x	○	x	x
	LC-40R30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40S5	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40SE1	○	○	○	○	○	○	x	○	○	x	x	x	x	○	○	x	x
	LC-40U20	○	○	x	○	○	○	x	○	○	x	x	x	x	x	○	x	○
	LC-40U30	○	○	x	○	○	○	x	○	○	x	x	x	x	x	○	x	○
	LC-40U40	○	○	x	○	○	○	x	○	○	x	x	x	x	x	○	x	○
	LC-40U45	○	○	x	○	○	○	x	○	○	x	x	x	x	x	○	x	○
	LC-40V5	○	x	x	x	x	x	x	x	x	x	x	x	x	x	○	x	x
	LC-40V7	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
LC-40W20	○	x	x	○	○	x	x	○	○	x	x	x	x	x	○	x	○	
LC-40W35	○	x	x	x	x	x	x	x	x	x	x	x	x	x	○	x	○	
LC-40W5	○	○	○	○	○	○	○	○	○	x	x	x	x	○	○	○	○	
LC-40Z5	○	x	○	x	○	x	○	○	○	x	x	x	x	○	○	x	x	
PN-B401	○	○	○	○	○	○	○	○	○	x	○	x	○	○	○	x	x	
PN-M401	○	○	○	○	○	○	○	○	○	x	○	x	○	○	○	x	x	
37	LC-37DS5	○	○	○	x	x	○	○	○	○	x	○	x	x	○	○	x	x
	LC-37ES50	○	○	○	x	x	○	○	○	x	○	x	x	○	○	x	x	
	LC-37EX5	○	○	○	x	x	○	○	○	x	○	x	x	○	○	x	x	
	LC-37GS10	○	○	○	○	x	○	○	○	x	○	x	x	○	○	x	x	
	LC-37GX3W	○	○	○	x	x	○	○	○	x	○	x	x	○	○	x	x	
	LC-37GX5	○	○	○	x	x	○	○	○	x	○	x	x	○	○	x	x	
32	2T-C32AE1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	2T-C32DE	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	2T-C32EF1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	2T-C32GF1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	2T-C32GE1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-32BD1	○	○	○	○	x	○	○	x	○	x	○	x	x	○	○	x	○
	LC-32BH11	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-32BH30	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-32D10	○	○	○	○	x	○	○	x	○	x	○	x	x	○	○	x	○
	LC-32D30	○	○	○	○	x	○	○	x	○	x	○	x	x	○	○	x	○
	LC-32DE5	○	○	○	○	x	○	○	x	○	x	○	x	x	○	○	○	○
	LC-32DR3	○	○	○	○	x	○	x	x	○	x	x	x	x	○	○	○	○
	LC-32DX3	○	○	○	○	x	○	x	x	○	x	x	x	x	○	○	x	○
	LC-32E40	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-32E7	○	○	○	○	x	○	○	x	○	x	○	x	x	○	○	x	○
	LC-32E8	○	○	○	○	x	○	○	x	○	x	○	x	x	○	○	○	○
LC-32ES	○	○	○	○	x	○	x	x	○	x	x	x	x	○	○	x	○	

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA034	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	40~85型	~50型	32~75型	32~75型	32~65型	50~85型	32~65型	42~100型	37~70型	~100型	32~65型	43型まで	15~43型
							縦設置専用											
32	LC-32F3	○	○	○	○	×	○	×	×	○	×	×	×	×	○	○	○	○
	LC-32F5	○	○	○	○	×	○	×	×	○	×	×	×	×	○	○	○	○
	LC-32GH1	○	○	○	○	×	○	○	×	○	×	○	×	×	○	○	×	×
	LC-32H11	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32H20	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32H30	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32H40	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32H9	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32J10	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32J9	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32R30	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-32R5	○	○	○	○	×	○	×	○	○	×	×	×	×	○	○	○	○
	LC-32S5	×	○※1	×	×	×	○※1	×	×	×	×	×	×	×	×	×	×	○
	LC-32SC1	○	○	○	○	×	○	×	×	○	×	×	×	×	○	○	○	○
	LC-32V5	○	○	×	×	×	○	×	×	×	×	×	×	×	×	○	○	○
	LC-32W25	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
LC-32W5	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○	
PN-Y326	○	○	○	○	×	○	○	×	○	×	○	×	×	○	○	○	○	
PN-Y326B	○	○	○	○	×	○	○	×	○	×	○	×	×	○	○	○	○	
24	2T-C24AD	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-24P5	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
22	2T-C22AD	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-22K45	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
19	2T-C19AD	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-19P5	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○

※1 ネジが付属しておりません
取り付けネジが別途必要です。(M4など)
※2 縦向き設置のみ可能

※3-2 別途変換金具 EEX-VESATF02 が必要です
テレビを取付のネジは別途必要な場合があります。
※3-3 別途変換金具 EEX-VESATF03 が必要です
テレビを取付のネジは別途必要な場合があります。

※4 ブラケットがテレビ下部よりはみ出す可能性があります。